



If you are installing Solid Mount fender guards it is necessary to remove the headlight bezel as well as the headlight assembly from the Pod. The headlight assembly secures the top of the fender guard to the truck.

30080-IN