

Blind Mount Drop Visor for 2005 and newer Flat Top with cab mounted mirrors

Remove factory visor and brackets. Drill out factory holes to 1/2". Install new brackets in factory locations using supplied hardware. The center brackets will require additional holes. Fasten visor skins to brackets using supplied hardware.

