

Blind Mount Drop visor for 1988-2005 Flat Top with door mounted mirrors

Ends have nutserts
for fastening
visor to brackets

you must
drill for this hole

Remove factory visor and brackets. Drill out factory holes to 1/2". Install new brackets in factory locations using supplied hardware. The center brackets will require additional holes. Fasten visor skins to brackets using supplied hardware

The outside brackets are additional brackets and will not have factory holes. They will have to be drilled at the 9th rivet locations

